
CD RECEIVER

KDC-8007/8008/9050R

SERVICE MANUAL

KENWOOD


© 1997-2 PRINTED IN JAPAN B51-7127-00 (N) 3610




Extension cord for service (W05-0618-00) 22P

Photo is KDC-8007. K1=KDC-8007, M2=KDC-8008, E1=KDC-9050R

BLOCK DIAGRAM: MECHANISM



BLOCK DIAGRAM: UNIT



CIRCUIT DESCRIPTION

 $\textbf{Microprocessor}: \mu \textbf{PD178016GC} \text{ (IC1, X25-)}$

Terminal description

No.	Pin name	I/O	Port name	Function	Active
1	ANI0	I	NOISE	FM noise detection analog input.	
2	ANI1	I	SMETER	FM S-meter detection analog input.	
3	ANI2		VALET (K, M)	Valet/demonstration input.	< 1V : Valet, > 4V : Demonstration
	ANIZ	'	PHONE (E)	Phone/Navigation muting input.	< 1V : Phone, > 4V : Navigation muting
4	P13	I	SRM SW1	Position detection input 1 from SRM.	"H" : ON
5	P14	0	MOTOR	Motor control output.	"H" : Loading, "L" : Eject
6	P15	I/O	LO/EJ	Loading/Ejection switching output.	"L" : Loading, "H" : Eject, Input : Stop
7	SI1	ı	L DATAL	Data input from LCD driver.	
8	SO1	0	L DATAS	Data output to LCD driver.	
9	SCK1	0	L CLK	Clock output to LCD driver.	
10	P23	0	L CE	CE output to LCD driver.	
11	P24	0	LINH	Reset output to LCD driver.	"L" : RESET
12	SI0	I	DATA C	Data input from changer.	
13	SO0	0	DATA H	Data output to changer.	
14	SCK0	ı	CH CLK	Clock input from changer.	
15	P132	0	M CS	Handshake request to CD mechanism controller.	"L" : Requested
16	P33	0	NC	Not used.	
17	P33	0	IFC	AM IF count control output.	"L" : ON
18	P40	1	CD SW1	Loading detection switch.	"L ": ON
19	P41	1	CD SW2	12cm disc detection switch.	"L ": 12cm disc ON
20	P42	1	CD SW3	Down and Limit switch.	"L" : Chucking
21	GND	_	GND	GND.	
22	VDD	_	VDD	5V.	
23	P43	Ī	QUAL	RDS reception quality.	
24	P44	ı	R DATA	RDS data input.	
25	P45	ı	NC	Not used.	
26	P46	1	NC	Not used.	
27	P47	I	FM MUTE	Band muting detection input.	"L" : Station detected
28	AMIFC	-	AM IFC	AM IF count input.	
29	FMIFC	_	FM IFC	FM IF count input.	
30	VDDPLL	_	VDD	5V.	
31	VCOH	_	FM IN	FM OSC input.	
32	VCOL	_	AM IN	AM OSC input.	
33	GNDPLL	-	GND	GND.	
34	EO0	-	EO0	PLL error output 0.	
35	EO1	_	EO1	PLL error output 1.	
36	IC (VPP)	-	VPP	GND.	
37	P50	0	LPF (E)	Low-pass filter switching output.	"L" : ON
38	P51	0	AFC	AFC output.	"L" : ON
39	P52	0	SRM SUB-	Storage motor driver control terminal.	
40	P53	0	SRM SUB+	Storage motor driver control terminal.	

CIRCUIT DESCRIPTION

No.	Pin name	I/O	Port name	Function	Active
41	P54	ı	AF SD	AM station detection input.	"H" : Sation detected
40	DEE		ANT CONT	Antenna control output.	"H" : ON
42	P55	0	LOCAL (E)	Local output.	"H": ON
43	P56	0	FM+B	FM power supply output.	"H": ON
44	P57	0	AM+B	AM power supply output.	"H": ON
45	P60	0	SCK	Clock output to electronic volume.	
46	P61	1/0	SDA	Data input/output to/from electronic volume.	
47	P62	0	MUTE	Muting output.	"H" : Mute ON
48	P63	0	CRSC (K, M)	CRSC output.	"H" : ON
40	F03		AF MUTE (E)	AF muting output.	"L": ON
49	P64	0	P STBY	Power amp standby output.	"H" : ON
50	P65	ı	ACC	ACC detection input.	"L" : ON
51	P66	ı	BU DET	Momentary power-down detection input.	"H" : Power-down
52	P67	0	TEST	High temperature protection circuit operation inhibition output.	"H" : Test mode
53	P30	0	P CON	Power control output.	"H": ON
54	P31	0	PON	μ-com and surrounding power control output.	"H" : ON
55	P32	0	ILL ON	Illumination output.	"H": Lit
56	P33	0	CH CON2	Changer 2 control output.	"H" : CH2 ON
57	P34	0	CH CON1	Changer 1 control output.	"H" : CH1 ON
58	P35	0	REQ H	Handshake request to changers.	"L" : Request
59	BUZ	0	BEEP	Beep output.	
60	P37	ı	E2DTI	Data input from E2PROM.	
61	P120	0	E2CE	CS output to E2PROM.	
62	P121	0	MCLK/E2CK	Clock output to CD mechanism controller/E2PROM.	
63	P122	I	DATA M	Data input from CD mechanism controller.	, , , , , , , , , , , , , , , , , , ,
64	P123	0	DATA S/E2DIO	Data output to CD mechanism controller.	
65	P124	1	SRM SW2	Position detection input 2 from SRM.	"L": ON
66	P125	ı	SRM DET	Storage mechanism detection.	"L" : SRM detected
67	INTP0	ı	REMO	Remote control signal input.	: Request
68	INTP1	1	R CLK	RDS clock input.	
69	INTP2	1	REQ C	Handshake request from changer.	"L" : Request
70	INTP3	0	M RST	Reset output to CD mechanism controller.	"L" : Reset
71	P04	1	M MUTE	Muting request from CD mechanism controller.	"L" : Request
72	P05	ı	M SRQ	Handshake request from CD mechanism controller.	: Request
73	P06	0	M STOP	Stop request to CD mechanism controller.	"L" : Request
74	CPUREQ	_	VDD	5V.	
75	GND	_	GND	GND.	
76	X2	-	X2	X'tal oscillator connection.	
77	X1	-	X1	X'tal oscillator connection.	
78	OSCREG	-	VDD	Oscillator power supply.	
79	VDD	-	VDD	Power voltage application terminal.	
80	RESET	_	RESET	Reset input.	

ADJUSTMENT


No.	ITEM	INPUT SETTING	OUTPUT SETTING	TUNER (RECEIVER)	ALIGNMENT POINTS	ALING FOR	FIG.
FM	section			·			
1	DISCRIMINATOR	(A) 98.1MHz Odev 60dBµ (ANT input)	Connect a DC voltmeter to CN8.	FM 98.1MHz	T1	OV	(a)
2	ANRC	* (C) 98.1MHz 1kHz, ±67kHz dev Pilot: ±7.5kHz dev Selector: L or R 35dBμ (ANT input)	(B)	FM 98.1MHz	VR1	Separation 10dB	

*KDC-9050R ...

(C)


98.1MHz

1kHz, ±40kHz dev Pilot : ±6kHz dev



PC BOARD (COMPONENT SIDE VIEW)

ELECTRIC UNIT: X25-781X-XX (8007: 0-11, 8008: 0-22, 9050R: 2-71)




(X25-781X-XX)

IC	1	2	3	4	5	6	7	8	9	10	11	12	13	14
address	4C	4E	3C	2E	4D	5B	4C	4B	5D	3D	3D	5F	5E	4F


Q	1	2	3	4	5	6	7	8	9	10	11	12	13	14	17	18	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
address	3B	3B	3C	3C	5B	3C	4C	3B	5B	5C	5B	5B	5B	5B	5F	5F	4B	4B	4C	3B	4B	4C	4B	4B	3F	2F	2F	2F	3F	2F	3C	2E


Ω	37	38	39	40	41	42	50	51	52	53	60	61	62	64	65	66	67	70	71	72	74	75	76	77	78	79	80	82	83	84	85	86
address	3C	5E	4C	4C	3E	3E	5D	4D	4D	4E	3E	4E	4E	3D	3D	3D	3D	3F	3F	4E	4E	4E	3G	3F	4E	3F	3F	4F	4F	4F	4F	4F

SWITCH UNIT: X13-9052-70




CD PLAYER UNIT: X32-4290-00






SWITCH UNIT: X13-9052-70



CD PLAYER UNIT: X32-4290-00



(X13-9052-70)


-	IC	Q	address
-	1		2M
	2		2K
	3		2J
		1	2M
		2	2J
		3	2L
		4	2L


(X32-4290-00)


Q	address
	4J
	5J
	6K
	6M
	5J
	5K
1	4K
2	6K
3	5K
5	6J
6	5K
	1 2 3 5


Refer to the schematic diagram for the values of resistors and capacitors.

74 75 76 77 78 79 80 82 83 84 85 86 4E 4E 3G 3F 4E 3F 3F 4F 4F 4F 4F 4F










SWITCH UNIT : X13-9052-70




(X13-9052-70)


IC	Q	address
1		2AV
2		2AX
3		2AY
	1	2AV
	2	2AY
	3	2AW
	1	2 4 1 4 /

(X32-4290-00)

A3	2-42	(00-06
IC	Q	address
1		4AY
2		5AY
3		6AX
4		6AV
5		5AY
6		5AX
	1	4AX
	2	6AX
	3	5AX
	5	6AY



Refer to the schematic diagram for the values of resistors and capacitors.




(X25-781X-XX)


10						U	,	U	J 1	0 11	14	10
address	4BF	4BD	3BF	2BD	4BE	5BG	4BF	4BG	5BE 31	BE 3BI	E 5BC	5BD
0	1	2	2	1	-		7	0	0 1	0 11	10	10

	000	000	005	005	-00	005		00000		-00	-00	
address	13BG	380	3BF	3BF	5BG	3BF	4BF	3BG 5BG	5BF	bBla	586	


Q	37	38	39	40	41	42	50	51	52	53	60	61	
address	3BF	5BD	4BF	4BF	3BD	3BD	5BE	4BE	4BE	4BD	3BD	4BD	4








ELECTRIC UNIT: X25-781X-XX (8007: 0-11, 8008: 0-22, 9050R: 2-71)



(X25-781X-XX)

IC 1 2 3 4 5 6 7 8 9 10 11 12 13 14 address 4BF 4BD 3BF 2BD 4BE 5BG 4BF 4BG 5BE 3BE 3BE 5BC 5BD 4BC

Q 1 2 3 4 5 6 7 8 9 10 11 12 13 14 17 18 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 address 3BG 3BF 3BF 5BG 3BF 4BF 3BG 5BG 5BG 5BG 5BG 5BG 5BG 5BC 5BC 4BG 4BG 4BF 3BG 4BG 4BG 4BG 4BG 3BC 2BC 2BC 2BC 3BC 2BC 3BC 2BC 3BF 2BD



BW


CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list). △ Indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse (s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.

• The DC voltage is an actual reading measured with a high impedance type voltmeter. The measurement value may vary depending on the measuring instruments used or on the product.

BS

BU






CAUTION: For continued safety, replace safety critical components only with manufacturer's recommended parts (refer to parts list).

△ Indicates safety critical components. For continued protection against risk of fire, replace only with same type and rating fuse (s). To reduce the risk of electric shock, leakage-current or resistance measurements shall be carried out (exposed parts are acceptably insulated from the supply circuit) before the appliance is returned to the customer.


• The DC voltage is an actual reading measured with a high impedance type voltmeter. The measurement value may vary depending on the measuring instruments used or on the product.

KDC-8007/9050R KENWOOD

EXPLODED VIEW (MECHANISM)



EXPLODED VIEW (UNIT)



PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-8007/8008/9050R

Ref	Ref No. Parts No. Description/Destination			Ref I	No.	N e w	Parts No.	Description/Destination		
KDC-8007/8008/9050R				Δ	F1	2 D		F52-0006-05	FUSE(MINI BLADE TYPE)	
202 203 204 205 206	1D 2D 1C 1D 1D		A10-4308-02 A10-4315-04 A10-4317-04 A10-4319-04 A10-4321-04	CHASSIS ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY CHASSIS CALKING ASSY		257 258 259 260 261	1 D 1 D 1 D 1 D 1 D		G01-2816-04 G01-2817-04 G01-2818-04 G01-2819-04 G01-2820-04	TORSION COIL SPRING TORSION COIL SPRING EXTENSION SPRING TORSION COIL SPRING TORSION COIL SPRING
207 210	1 D 3C		A10-4353-03 A22-1293-03	CHASSIS ASSY SUB PANEL ASSY		262	1 D		G11-1733-04	CUSHION
212 213 PA1 PA1 PA1	2C 1D 3C 3C 3C		A46-1243-03 A46-1260-02 A52-0710-02 A64-1042-02 A64-1045-02 A64-1047-02	REAR COVER TOP PLATE PANEL ASSY (KDC-8007) PANEL ASSY (KDC-8008) PANEL ASSY (KDC-9050R)		-			H10-4560-02 H13-1681-04 H25-0329-04 H25-0337-04 H25-1108-04	POLYSTYRENE FOAMED FIXTURE CARTON BOARD PROTECTION BAG(280X450X0.03)K1M2 PROTECTION BAG(180X300X0.03) PROTECTION BAG(100X300X0.03)M2E1
RM1 220 221 222	1C 2C 1C 3C	*	A70-0860-05 B03-3021-04 B07-2087-02 B07-2096-02	REMOTE CONTROLLER ASSY(9050R) DRESSING SEAL ESCUTCHEON ESCUTCHEON		 			H25-1111-04 H54-0786-04 H54-0789-04 H54-0791-04	PROTECTION BAG(280X450X0.03)E1 ITEM CARTON CASE K1 ITEM CARTON CASE M2 ITEM CARTON CASE E1
223 223 223	3C 3C 3C		B10-1754-01 B10-1757-01 B10-1759-01 B46-0100-50	FRONT GLASS FRONT GLASS FRONT GLASS WARRANTY CARD		265 266 267 268 270	1 C 1 C 1 C 1 D 1 D		J19-4720-04 J19-4721-04 J21-7630-33 J21-7768-04 J21-7777-04	BRACKET K1M2 BRACKET K1M2 MOUNTING HARDWARE ASSY MOUNTING HARDWARE ASSY MOUNTING HARDWARE
-			B46-0172-13 B46-0612-14 B64-0979-00 B64-0980-00 B64-0981-00	QUESTIONAIRE CARD ID CARD INST.MANUAL(ENG,FRE) INST.MANUAL(SPA) INST.MANUAL(ENG,CHI)		271 272 FPC1 FPC2 FPC3	1 D 1 C 3 D 1 D 2 C		J31-1035-04 J54-0606-04 J84-0061-03 J84-0062-03 J84-0066-03	COLLAR STAY FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD FLEXIBLE PRINTED WIRING BOARD
- - -			B64-0982-00 B64-0983-00 B64-0984-00 B64-0985-00	INST.MANUAL(ENG,FRE) INST.MANUAL(GER,ITA) INST.MANUAL(DUT,POR) INST.MANUAL(SPA)		275 276 277 278 279	30 30 30 30 30		K24-1767-04 K25-0794-03 K25-0795-03 K25-0796-03 K25-0798-03	KNOB(RESET) KNOB(VOL.) KNOB(PRESET) KNOB(FM,AM) KNOB(CD,CH)
225 230 231 232	1 C 1 D 1 D 1 D		D10-4067-04 D10-4135-04 D10-4136-04 D13-1302-04	LEVER ARM ASSY ARM ASSY GEAR ASSY		280 281	3C 3C		K25-0799-03 K25-0803-03	KNOB(CLK) KNOB(AUD)
233 234 235 236 239	1 D 1 D 1 D 1 D 1 D		D13-1306-04 D13-1307-03 D13-1308-04 D13-1309-04 D13-1312-04	GEAR GEAR GEAR GEAR GEAR		282 283 A B C	1C 1C 3D 2C 3C		N09-1885-05 N99-1622-05 N83-3005-46 N67-3005-46 N30-2003-46	SEMS (MACHINE SCREW) E1 SCREW SET K1M2 PAN HEAD TAPTITE SCREW PAN HEAD SEMS SCREW PAN HEAD MACHINE SCREW
240 242 243 244 246	1 D 1 D 1 D 1 D 1 D		D13-1313-04 D13-1315-04 D13-1320-03 D13-1321-03 D14-0678-04	GEAR GEAR GEAR ASSY GEAR ASSY ROLLER ASSY		DEFGH	1D 3C 2D 1D 3C		N09-4184-05 N80-2005-46 N80-2008-46 N80-2006-45 N35-2003-45	MACHINE SCREW (M2X2 2527070x) PAN HEAD TAPTITE SCREW PAN HEAD TAPTITE SCREW FLAT HEAD TAPTITE SCREW BINDING HEAD MACHINE SCREW
247	3D		D14-0680-04	ROLLER		J K	1 D 1 D		N19-2062-04 N19-2022-04	FLAT WASHER FLAT WASHER
248 250 251	3D 2D 2D		D14-0681-04 E30-4447-05 E30-4448-05	ROLLER CORD WITH PINPLUG(RCA) CORD WITH DIN CONNECTOR(CH)		M Q R	3D 1D 1D		N35-2004-46 N19-2058-04 N19-2094-04	BINDING HEAD MACHINE SCREW FLAT WASHER FLAT WASHER
DC1 DC2	1C 1C		E30-4435-05 E30-4437-05	DC CORD DC CORD		S1	1 D		S68-0822-05	PUSH SWITCH
252 255	1 D 2 D		F09-1244-04 F29-0049-05	SHEET INSULATING COVER		284 M1	1 C 1 D		T90-0512-05 T42-0752-04	ANTENNA ADAPTOR E1 MOTOR ASSY

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

 $\underline{\mathbb{M}}$ indicates safety critical components.

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

KDC-8007/8008/9050R SWITCH UNIT (X13-9052-70) **ELECTRIC UNIT (X25-781X-XX)**

K1 · 0-11 M2 · 0-22 F1 · 2-71

Ref No.	Zes	Parts No.	Description/Destinat	ion R	ef No.
ME1 2C		X92-3190-00	MECHANISM ASSY	C1	
			IIT (X13-9052-70)		
D1 -9 LCD1 2C PL1 -4		B30-1349-05 B38-0671-05 B30-1478-05	LED LIQUID CRYSTAL LAMP (5.5V .		8
C1 C2 ,3 C4 C5 C6		CK73FB1H821K CK73FB1H473KTA CK73FB1H103K C92-0509-05 CK73FB1H103K	CHIP C 0.047UF CHIP C 0.010UF CHIP-TAN 10UF	K C2 K C2 C2 C2 C3 K C2 C2 C2	0 1 2 3
C7 C8 ,9 C10		CK73FB1H821K CK73FB1H473KTA CK73FB1H103K	CHIP C 0.047UF	K C2 K C2 K C2 C3	5 ,26 7 8 ,29
303 CN1		E29-1520-04 E40-9407-05	CONDUCTIVE RUBBER FLAT CABLE CONNECTOR	C3	1
L1 ,2		L40-4795-34	SMALL FIXED INDUCTOR	C3	3 -35
CP1 CP2 R8 R9		R90-1016-05 R90-0725-05 RK73FB2A683J RK73FB2A472J		1/10W C3 1/10W C3 1/10W C3	7,38 9
R10 R11		RK73FB2A101J RK73FB2A683J	CHIP R 100 J	1/10W C4 C4:	1,42
R12 R13 -15 R16 -19 R20		RK73FB2A473J RK73EB2B331J RK73EB2B471J RK73EB2B331J	CHIP R 330 J CHIP R 470 J	1/10W 1/8W C4- 1/8W C4- 1/8W C4-	4 5
R21 -24 R25 ,26		RK73EB2B130J RK73FB2A273J		1/8W C40	5
S1 -4 S6 -11 S12 -21 S22		S70-0839-05 S70-0839-05 S70-0813-05 S40-1601-15	TACT SWITCH TACT SWITCH TACT SWITCH PUSH SWITCH	C4 C4 C5 C5 C5	3,49 0 1
IC1 IC2 IC3 Q1 ,2		LC75853NE LC75833E PAS-B06B1FE DTA114EK UN2111	M0S-IC M0S-IC ANALOGUE IC DIGITAL TRANSISTOR DIGITAL TRANSISTOR	C5: C5: C5: C5:	4 5 5
Q3 ,4		2SD2114K	TRANSISTOR	C5	
			IT (X25-781X-XX)		,61
C1 C2 C3 C4		C90-2822-05 CK73FB1H103K CE04CW1C101M CK73FB1H103K	CHIP C 0.010UF PELECTRO 100UF	[6MA] C94	
C5		C90-2594-05		LOWV C6	5 -69
C6 C7 C8		CE04CW0J101M CK73FB1H102K CE04CW1A221M	CHIP C 1000PF	5.3WV C72 C74	2 ,73
C9 C10		CE04CW1A101M CK73EB1C225K	ELECTRO 100UF	0WV 075	5
C11 C12 ,13		C90-2595-05 CK73EB1C225K	ELECTRO 4.7UF CHIP C 2.2UF	.6WV C71	7

N e Parts No.	 -	K1 : 0-11 Desc	M2 : 0-2		: 2-71
	CK73FB1H223KTA C90-2840-05 CE04CW1C220M CE04CW1E100M CK73FB1H103K	CHIP C ELECTRO ELECTRO CHIP C	0.022UF 100UF 22UF 10UF 0.010UF	K 16WV 16WV 25WV K	
19 20 21 22 23	CE04CW1C101M CK73FB1H103K C90-2602-05 CK73FB1E683KTA C90-2598-05	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	100UF 0.010UF 0.10UF 0.068UF 3.3UF	16WV K 50WV K 25WV	
024 025 ,26 027 028 ,29	CK73FB1H102K CK73FB1H103K CK73FB1C104K CC73FCH1H22OJ CK73FB1C104K	CHIP C CHIP C CHIP C CHIP C	1000PF 0.010UF 0.10UF 22PF 0.10UF	K K K J K	
031 032 033 -35 033 -36 037 ,38	CK73FB1H223KTA CC73FCH1H331J CK73FB1H103K CK73FB1H103K CE04CW0J470M	CHIP C CHIP C CHIP C CHIP C ELECTRO	0.022UF 330PF 0.010UF 0.010UF 47UF	K J K K 6.3WV	M2 K1E1
039 039 ,40 041 ,42 042 043	CK73FB1H103K CK73FB1H103K CE04CW1A101M CE04CW1A101M C93-1052-05	CHIP C CHIP C ELECTRO ELECTRO CERAMIC	0.010UF 0.010UF 100UF 100UF 6800PF	K K 10WV 10WV K	K1M2 E1 E1 K1M2 E1
044 045 046 046	CK73FB1C104K CK73FB1E683KTA C93-1062-05 C90-2525-05 C90-2807-05	CHIP C CHIP C CHIP C NP-ELECT NP-ELEC	0.10UF 0.068UF 0.033UF 2.2UF 0.47UF	K K K 35WV 50WV	K1M2 E1 E1 K1M2 E1
47 48,49 50 51 52	CK73FB1H103K CK73FB1C104K CK73FB1C224K CK73FB1H103K CK73FB1H223KTA	CHIP C CHIP C CHIP C	0.010UF 0.10UF 0.22UF 0.010UF 0.022UF	К К К К	
053 054 055 056 057	CK73FB1C224K CK73FB1C104K CK73FB1H103K CF0-2597-05 CK73EB1C225K	CHIP C CHIP C CHIP C ELECTRO CHIP C	0.22UF 0.10UF 0.010UF 10UF 2.2UF	K K K 16WV K	
058 059 060 ,61 062 ,63	CE04CW1C470M CK73FB1E473KTA C90-2595-05 CK73FB1H152K CE04CW1A101M	ELECTRO CHIP C ELECTRO CHIP C ELECTRO	47UF 0.047UF 4.7UF 1500PF 100UF	16WV K 16WV K 10WV	K1M2
65 66 -69 70 ,71 72 ,73	CK73FB1H103K CK73FB1C104K C90-2597-05 CK73FB1H222K C90-2608-05	CHIP C CHIP C ELECTRO CHIP C ELECTRO	0.010UF 0.10UF 10UF 2200PF 1.0UF	K K 16WV K 50WV	
75 75 76 77	CK73FB1C104K CK73FB1H103K CK73FB1H102K CK73FB1H223KTA CK73FB1H102K	CHIP C CHIP C CHIP C CHIP C CHIP C	0.10UF 0.010UF 1000PF 0.022UF 1000PF	К К К К	K1M2 E1
					1

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

Ref No.	N e Parts No. Description/Destination		Ref No.	Parts No.	T	ption/Destina	ition	
C79 C80 C81 C82 C83	CK73FB1C154K C90-2608-05 CK73EB1C105K C90-2610-05 CK73FB1H223KTA	CHIP C 0.15UF ELECTR® 1.0UF CHIP C 1.0UF ELECTR® 2.2UF CHIP C 0.022UF	K 50WV K 50WV K	C215 C216 C217 C218 C219	CE04CW1A101M CK73FB1H103K CK73FB1C823K CK73FB1H223KTA CE04CW1A330M	CHIP C CHIP C CHIP C	0.010UF K 0.082UF K 0.022UF K	wv
C84 C85 C86 C87 C88	C90-2610-05 CC73FCH1H271J CK73FB1E473KTA CK73FB1C823K CK73FB1H272K	ELECTRO 2.2UF CHIP C 270PF CHIP C 0.047UF CHIP C 0.082UF CHIP C 2700PF	50WV J K K K	C220 C221 C222 C222,223 C223	CK73FB1H103K CE04CW1A101M CK73FB1H103K CK73FB1H103K CK73FB1H102K	CHIP C	0.010UF K 100UF 10 0.010UF K 0.010UF K 1000PF K	WV M2E1 K1 E1
C89 C90 C91 C92 ,93	CC73FCH1H120J C90-2594-05 CK73FB1H103K CC73FSL1H122J CC73FCH1H060D	CHIP C 12PF ELECTRO 10UF CHIP C 0.010UF CHIP C 1200PF CHIP C 6.0PF	J E1 10WV E1 K E1 J E1 D E1	C224 C225 C226 C227 C228	CK73FB1H103K CC73FCH1H820J CC73FCH1H470J CK73FB1H103K C90-2608-05	CHIP C CHIP C CHIP C	0.010UF K 82PF J 47PF J 0.010UF K 1.0UF 50	E1 E1 E1 E1
C95 C96 C97 C98 C99	CC73FCH1H471J CC73FCH1H820J CK73FB1H223KTA CC73FCH1H121J CC73FSL1H102J	CHIP C 470PF CHIP C 82PF CHIP C 0.022UF CHIP C 120PF CHIP C 1000PF	J E1 J E1 K E1 J E1 J E1	C229 C229,230 C231 C232 C233	CK73FB1H103K CK73FB1H103K CK73FB1C104K CC73FCH1H181J CK73FB1H103K	CHIP C CHIP C CHIP C	0.010UF K 0.010UF K 0.10UF K 180PF J 0.010UF K	K1M2 E1 E1
C100 C101 C102-106 C110 C111,112	CC73FCH1H471J CC73FSL1H222J CK73FB1H103K C90-2595-05 CE04CW0J470M	CHIP C 470PF CHIP C 2200PF CHIP C 0.010UF ELECTRØ 4.7UF ELECTRØ 47UF	J E1 J E1 K 16WV 6.3WV	CN1 CN2 CN3 CN4	E23-0732-04 E40-3243-05 E40-3237-05 E40-3252-05 E40-3261-05	TERMINAL PIN ASSY PIN ASSY PIN ASSY PIN ASSY		
C113 C114-121 C122-125 C126 C127	C90-2595-05 CK73FB1C274K CK73EB1C225K C90-2608-05 CE04CW1A330M	ELECTR® 4.7UF CHIP C 0.27UF CHIP C 2.2UF ELECTR® 1.0UF ELECTR® 33UF	16WV K K 50WV 10WV	CN5 CN6 CN7 CN8 △ J1	E40-9550-05 E40-9557-05 E40-5029-05 E40-3640-05 E58-0836-05	FLAT CABLE FLAT CABLE FLAT CABLE PIN ASSY RECTANGULA	CONNECTOR	E
C128 C129-132 C135-140 C143,144 C145-152	CK73FB1H103K C90-2597-05 C90-2597-05 C90-2597-05 CK73FB1H153KTA	CHIP C 0.010UF ELECTR® 10UF ELECTR® 10UF ELECTR® 10UF CHIP C 0.015UF	16WV 16WV 16WV	WH1 2D CF1 ,2 CF1 ,2 L1 -6 L1 ,2	E30-4452-05 L72-0719-05 L72-0720-05 L40-4795-34 L40-4795-34	CORD WITH CERAMIC FI CERAMIC FI SMALL FIXE SMALL FIXE	LTER LTER D INDUCTOR	K1M2 E1 E1 K1M2
C153 C154 C155-158 C159 C161	C90-2597-05 CE04CW1A101M CK73FB1C224K C90-2608-05 C90-2598-05	ELECTRO 10UF ELECTRO 100UF CHIP C 0.22UF ELECTRO 1.0UF ELECTRO 3.3UF	16WV 10WV K 50WV 25WV	L4 -6 L7 L8 L9	L40-4795-34 L40-4791-17 L33-1039-05 L40-2205-34 L30-0730-05	SMALL FIXE	D INDUCTOR D INDUCTOR	K1M2 4.7UH,K)
C200,201 C202 C203 C204 C205	CK73FB1H103K CK73FB1H822K CK73FB1H102K CK73FB1H103K C92-0005-05	CHIP C 0.010UF CHIP C 8200PF CHIP C 1000PF CHIP C 0.010UF CHIP-TAN 2.2UF	K E1	X1 X1 X2 X3	L77-1163-05 L77-1165-05 L78-0545-05 L77-2002-05			
C206 C207 C208 C209 C210	CK73FB1H103K CC73FCH1H331J C90-2597-05 CE04CW1A330M CC73FCH1H561J	CHIP C 0.010UF CHIP C 330PF ELECTRO 10UF ELECTRO 33UF CHIP C 560PF	K J E1 16WV E1 10WV J E1	A 2D L 2D N 2D P 2D	N83-3005-46 N83-3020-46 N64-3010-46 N30-3005-46	PAN HEAD TAN HEAD SAN HEAD MAN	ACHINE SCRE	W
C211 C212 C213 C214 C214	CK73FB1H223KTA CK73FB1H103K CK73FB1H102K CK73FB1E473KTA CK73FB1H103K	CHIP C 0.010UE CHIP C 1000PF	K K K <u>K</u> 1M2	CP1 CP2 CP3 CP4 -7 R1	R90-0724-05 R90-0725-05 R90-1015-05 R90-0725-05 RK73FB2A223J	MULTI-COMP MULTI-COMP MULTIPLE RI MULTI-COMP CHIP R	1K X4 1K X2 ESISTOR 1K X2 22K J 1	/10 W

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1:0-11 M2:0-22 E1:2-71

		arts No. werden nich	T						T.	T	<u>K1 :</u>	0-11	M2	: 0-2	.Z E1	1:2-7
Ref No.	N e w	Parts No.	Des	cription/	Des	stinatio	n	Ref No.	N e w	Parts No.		Des	ription	/Des	tinatio	n
R2 R3 R4 R5 R6		RK73FB2A101J RK73EB2B221J R92-2046-05 R92-2039-05 RK73FB2A153J	CHIP R CHIP R CHIP R CHIP R CHIP R	100 220 4.3K 24K 15K	J D D J	1/10W 1/8W 1/10W 1/10W	į į	R68 ,69 R71 ,72 R72 R73 R74		RK73FB2A104J RK73FB2A104J RK73FB2A104J RK73FB2A470J RK73FB2A222J	CHIF CHIF CHIF CHIF	R R R	100K 100K 100K 47 2.2K	J	1/10W 1/10W 1/10W 1/10W	√ M2 √ K1E1 √
R7 R8 R9 ,10 R11 R12		RK73FB2A152J RK73FB2A102J RK73FB2A470J RK73FB2A332J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R	1.5K 1.0K 47 3.3K 100K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R76 R78 ,79 R81 R82 R83		RK73FB2A222J RK73FB2A102J RK73EB2B103J RK73EB2B102J RK73EB2B472J	CHIP CHIP CHIP CHIP	R R R	2.2K 1.0K 10K 1.0K 4.7K	J J J J	1/10W 1/10W 1/8W 1/8W 1/8W	
R15 R16 R17 R18 R19		RK73FB2A104J RK73FB2A102J RK73FB2A272J RK73FB2A563J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K 1.0K 2.7K 56K 10K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R85 R86 R87 R88 R89		RK73FB2A223J RK73FB2A472J R92-2063-05 RK73FB2A104J RK73FB2A102J	CHIP CHIP CHIP CHIP	R R	22K 4.7K 680 100K 1.0K	J J J J	1/10W 1/10W 1/2W 1/10W 1/10W	i I
R20 R21 R22 ,23 R24 R25		RK73FB2A913J RK73FB2A750J RK73FB2A470J RK73FB2A913J RK73FB2A153J	CHIP R CHIP R CHIP R CHIP R CHIP R	91K 75 47 91K 15K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W		R90 R91 R92 R93 R94		RK73FB2A470J RK73FB2A223J RK73FB2A104J RK73FB2A102J RK73FB2A223J	CHIP CHIP CHIP CHIP	R R R	47 22K 100K 1.0K 22K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	i I
R26 R28 R29 ,30 R31 R32 ,33		RK73FB2A163J RK73FB2A913J R92-0365-05 RK73FB2A223J RK73FB2A472J	CHIP R CHIP R CHIP R CHIP R CHIP R	16K 91K 1.0K 22K 4.7K	J J J	1/10W 1/10W 1/2W 1/10W 1/10W	K1M2	R96 R97 R99 R100 R101		RK73FB2A102J RK73FB2A223J RK73FB2A222J RK73FB2A472J RK73FB2A222J	CHIP CHIP CHIP CHIP	R R R	1.0K 22K 2.2K 4.7K 2.2K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1
R33 R34 R35 R37 R38		RK73FB2A472J R92-0366-05 RK73FB2A223J RK73FB2A104J RK73FB2A223J	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K 56C 22K 100K 22K	J J J J	1/10W 1W 1/10W 1/10W 1/10W	K1M2	R102 R103 R104 R105 R106		RK73FB2A472J RK73FB2A222J RK73FB2A103J RK73FB2A223J RK73FB2A472J	CHIP CHIP CHIP CHIP	R R R	4.7K 2.2K 10K 22K 4.7K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	
R39 ,40 R41 R42 R43 R44		RK73FB2A123J RK73FB2A562J RK73EB2B473J RK73FB2A622J RK73EB2B473J	CHIP R CHIP R CHIP R CHIP R CHIP R	12K 5.6K 47K 6.2K 47K	J J J J	1/10W 1/10W 1/8W 1/10W 1/8W		R109 R110 R111 R113 R117		RK73FB2A102J RK73FB2A562J RK73FB2A101J RK73FB2A104J RK73FB2A472J	CHIP CHIP CHIP CHIP	R R R	1.0K 5.6K 100 100K 4.7K	J J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1 K1M2
R45 R46 R47 R48 R49		RD14DB2H332J RK73FB2A473J RK73FB2A471J RK73FB2A104J RK73FB2A334J	SMALL-RD CHIP R CHIP R CHIP R CHIP R	3.3K 47K 470 100K 330K	J	1/2W 1/10W 1/10W 1/10W 1/10W		R118 R119,120 R123 R124 R130		RK73FB2A222J RK73FB2A104J RK73FB2A163J RK73FB2A183J RK73FB2A680J	CHIP CHIP CHIP CHIP CHIP	R R R	2.2K 100K 16K 18K 68	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1
R50 R51 -53 R54 R55 R56		RK73FB2A104J RK73FB2A102J RK73FB2A222J RK73FB2A102J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K 2.2K 1.0K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1	R132 R133 R134 R135 R136		RK73FB2A222J RK73FB2A223J RK73FB2A101J RK73FB2A562J RK73FB2A332J	CHIP CHIP CHIP CHIP	R R R	2.2K 22K 100 5.6K 3.3K	J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1 E1 E1
R56 -58 R57 R58 R59 R60	ĺ	RK73FB2A104J RK73FB2A223J RK73FB2A473J RK73FB2A102J RK73FB2A103J	CHIP R CHIP R CHIP R CHIP R CHIP R	47K 1.0K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1	R137 R137 R138 R139 R139		RK73FB2A102J RK73FB2A222J RK73FB2A302J RK73FB2A472J RK73FB2A561J	CHIP CHIP CHIP CHIP CHIP	R R R	1.0K 2.2K 3.0K 4.7K 560	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1 E1 E1
R61 -63 R64 R65 R66 R68			CHIP R CHIP R CHIP R CHIP R CHIP R	100K 2.2K	J J J	1/10W 1/10W 1/10W 1/10W 1/10W	E1	R140 R141 R142 R143 R144,145		RK73EB2B751J RK73FB2A331J RK73FB2A331J RK73FB2A104J RK73EB2B104J	CHIP CHIP CHIP CHIP CHIP	R R R	750 330 330 100K 100K	J J J	1/8W 1/10W 1/10W 1/10W 1/8W	K1M2

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1: 0-11 M2: 0-22 E1: 2-71

	irts No. werden nich	nt generert.	N _		K1:0-11 [VI2 : 0-22	2 E1:2-71
Ref No.	Parts No.	Description/Destination	Ref No. Ref No.	arts No.	Descrip	otion/Dest	ination
R146-148 R158 R164,165 R167 R168-170	RK73FB2A222J RK73EB2B472J R92-2104-05 RK73EB2B472J RK73EB2B102J	CHIP R 2.2K J 1/10W CHIP R 4.7K J 1/8W CHIP R 2.2 J 1W CHIP R 4.7K J 1/8W CHIP R 1.0K J 1/8W	R304 RK73 R305 RK73 R306 RK73	BFB2A682J BFB2A472J BFB2A222J BFB2A103J BEB2B102J	CHIP R 2 CHIP R 1	6.8K J 4.7K J 2.2K J 10K J 1.0K J	1/10W 1/10W 1/10W E1 1/10W 1/8W
R171 R172 R173 R174 R175	RK73EB2B470J RK73EB2B102J RK73EB2B470J RK73EB2B102J RK73EB2B100J	CHIP R 47 J 1/8W CHIP R 1.0K J 1/8W CHIP R 47 J 1/8W CHIP R 1.0K J 1/8W CHIP R 1.0K J 1/8W CHIP R 10 J 1/8W	R310 RK73 R311 RK73 R312,313 RK73	FB2A472J FB2A102J FB2A222J FB2A223J FB2A183J	CHIP R 2 CHIP R 2	4.7K J 1.0K J 2.2K J 22K J 18K J	1/10W 1/10W 1/10W 1/10W 1/10W K1M2
R176 R177 R200,201 R203 R205,206	RK73EB2B4R7J RK73EB2B100J RK73FB2A622J RK73FB2A332J RK73FB2A102J	CHIP R 4.7 J 1/8W CHIP R 10 J 1/8W CHIP R 6.2K J 1/10W CHIP R 3.3K J 1/10W CHIP R 1.0K J 1/10W	R315 RK73 R316 RK73 R317 RK73	FB2A203J FB2A153J FB2A473J FB2A562J FB2A472J	CHIP R CHIP R CHIP R	20K J 15K J 47K J 5.6K J 4.7K J	1/10W E1 1/10W 1/10W 1/10W 1/10W
R207 R208 R209 R210 R210	R92-2029-05 R92-2025-05 RK73FB2A393J RK73FB2A154J RK73FB2A184J	CHIP R 2.0K D 1/10W CHIP R 180 D 1/10W CHIP R 39K J 1/10W K1M2 CHIP R 150K J 1/10W K1M2 CHIP R 180K J 1/10W E1	R320 RK73 R321 RK73 R322 RK73	EB2B2R2J FB2A393J FB2A103J FB2A680J FB2A473J	CHIP R CHIP R CHIP R	2.2 J 39K J 10K J 68 J 47K J	1/8W 1/10W 1/10W 1/10W 1/10W
R211,212 R213 R214 R215 R216	RK73FB2A104J RK73FB2A683J RK73FB2A183J RK73FB2A753J RK73FB2A182J	CHIP R 100K J 1/10W CHIP R 68K J 1/10W CHIP R 18K J 1/10W CHIP R 75K J 1/10W E1 CHIP R 1.8K J 1/10W E1	R325 RK73 R326 RK73 R327 RK73	FB2A472J FB2A222J FB2A102J FB2A101J FB2A151J	CHIP R CHIP R CHIP R	4.7K J 2.2K J 1.0K J 100 J 150 J	1/10W E1 1/10W E1 1/10W E1 1/10W E1 1/10W
R217 R218,219 R220 R221 R222	RK73FB2A161J RK73FB2A103J RK73FB2A823J RK73FB2A153J RK73FB2A103J	CHIP R 160 J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 82K J 1/10W E1 CHIP R 15K J 1/10W E1 CHIP R 10K J 1/10W E1	R330 RK73 R331 RK73 R332 RK73	FB2A103J FB2A682J FB2A102J FB2A562J FB2A331J	CHIP R CHIP R CHIP R	10K J 6.8K J 1.0K J 5.6K J 330 J	1/10W 1/10W 1/10W 1/10W 1/10W
R223 R224 R225 R226 R231,232	RK73FB2A562J RK73FB2A103J RK73FB2A104J RK73FB2A103J RK73FB2A361J	CHIP R 5.6K J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 100K J 1/10W E1 CHIP R 10K J 1/10W E1 CHIP R 360 J 1/10W	R334 RK73 R335 RK73 R336 RK73	FB2A153J FB2A473J FB2A223J FB2A513J FB2A221J	CHIP R 2 CHIP R 2 CHIP R 5	15K J 47K J 22K J 51K J 220 J	1/10W K1M2 1/10W E1 1/10W 1/10W 1/10W E1
R233,234 R235,236 R237,238 R239,240 R241,242	RK73FB2A223J RK73FB2A104J RK73FB2A153J RK73FB2A223J RK73FB2A820J	CHIP R 22K J 1/10W CHIP R 100K J 1/10W CHIP R 15K J 1/10W CHIP R 22K J 1/10W CHIP R 82 J 1/10W	R339 RK73 R340 RK73 R341 RK73	FB2A561J FB2A560J FB2A222J FB2A331J 0212-05	CHIP R 5	560 J 56 J 2.2K J 330 J VARIABLE	1/10W E1 1/10W E1 1/10W E1 1/10W E1 E RESISTOR
R243,244 R245,246 R247,248 R249,250 R251,252	RK73FB2A361J RK73FB2A223J RK73FB2A104J RK73FB2A153J RK73FB2A223J	CHIP R 360 J 1/10W CHIP R 22K J 1/10W CHIP R 100K J 1/10W CHIP R 15K J 1/10W CHIP R 22K J 1/10W	W18 R92- W18 -21 R92- W19 -21 R92-	2052-05 2052-05 2052-05 2052-05 2052-05	CHIP R () J) J) J	1/10W K1M2 1/10W E1 1/10W M2 1/10W K1 1/10W E1
R253,254 R255 R256 R257-260 R262	RK73FB2A820J RK73FB2A103J RK73FB2A223J RK73FB2A472J RK73FB2A154J	CHIP R 82 J 1/10W CHIP R 10K J 1/10W CHIP R 22K J 1/10W CHIP R 4.7K J 1/10W CHIP R 150K J 1/10W	PH1 T95- D1 RM10		CHIP R (1/10W K1M2
R263 R264 R265-268 R301 R302	RK73FB2A751J RK73FB2A431J RK73FB2A223J RK73FB2A682J RK73FB2A222J	CHIP R 750 J 1/10W CHIP R 430 J 1/10W CHIP R 22K J 1/10W CHIP R 6.8K J 1/10W CHIP R 2.2K J 1/10W E1	D4 UZL-		DIODE DIODE ZENER DIODE ZENER DIODE ZENER DIODE	Ξ	
			D5 UZ-1	1BS(B)	ZENER DIODE	3 	

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

ELECTRIC UNIT (X25-781X-XX)

Ref No.	N e w	Parts No.	Description/Destinati	ion	Ref No.	N e w	Parts No.	K1: 0-11 M2: 0-22 Description/Destina	
D6 D7 D8 D9 ,10		MA3220H UZL-11(M3) UZL-6(M1) DA204K 1SS133	ZENER DIODE ZENER DIODE ZENER DIODE DIODE DIODE	:	Q9 Q9 Q10 Q10 Q11	[DTC144EK UN2213 DTA124EK UN2112 2SB1443	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR	
D12 ,13 D12 ,13 D13 D13 D14		AM01Z ERA15-01 AM01Z ERA15-01 MA3047M	DIODE DIODE DIODE DIODE ZENER DIODE	K1M2 K1M2 E1 E1	Q12 Q12 Q13 Q14 Q14	2	2SC2412K 2SD601A 2SB1184 2SC2412K 2SD601A	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D15 ,16 D17 D17 D18 -21 D22		UZL-6(M1) DAN202K MA152WK UZMA6.2F DAN202K	ZENER DIODE DIODE DIODE ZENER DIODE DIODE		Q17 Q18 Q18 Q21 Q21	2 2 2	2SB1443 2SC2412K 2SD601A 2SC2412K 2SD601A	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D22 D23 D30 D31 D50 ,51		MA152WK DA204K DA204K MA3068M DAN202K	DIODE DIODE DIODE ZENER DIODE DIODE	E1	Q22 ,23 Q24 -26 Q24 -26 Q27 Q28	2 2 2	2SA1037K 2SC2412K 2SD601A 2SB1443 2SA1037K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	
D50 ,51 D52 D53 ,54 D53 ,54		MA152WK UZMA6.8F DAP202K MA152WA DAN202K	DIODE ZENER DIODE DIODE DIODE DIODE	E1	Q29 ,30 Q29 ,30 Q30 Q30 Q31	ו נו	DTC114EK JN2211 DTC114EK JN2211 DTA124EK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	K 1 M K 1 M E 1 E 1
055 060 060 061 061		MA152WK DAP202K MA152WA DAN202K MA152WK	DIODE DIODE DIODE DIODE	K1 K1	Q31 Q32 Q33 ,34 Q34 Q35 ,36	2 2 2	JN2112 SSA1037K SSB1277(Q,R) SSB1277(Q,R) SSC2412K	DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	K 1 M. E 1
IC1 IC1 IC2 IC3 IC4		178016BGC519 178018BGC514 TDA7420 HD74HC27FP TDA7384A	MI-COM IC MI-COM IC ANALOGUE IC MOS-IC ANALOGUE IC	K1M2 E1	Q35 ,36 Q37 Q37 Q38 Q38	D U D	RSD601A DTA124EK DN2112 DTC144EK UN2213	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
[05 [06 [07 [08 [09		TDA7435 M5237ML KKZ01F TC7660SE0A TC4W66F	ANALOGUE IC IC(VOLTAGE REGULATOR) CUSTOM IC ANALOGUE IC IC	K1E1 E1	Q39 Q39 Q40 Q40 Q41	U D U	TC124EK N2212 TA124EK N2112 TC124EK	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	
IC10,11 IC12 IC13 IC14		NJM4565M-TE2 BA6219BFP-Y SAA6579T LA1145M 2SB1565F(E,F)	ANALOGUE IC ANALOGUE IC IC ANALOGUE IC TRANSISTOR	E1	Q41 Q42 Q42 Q50 Q50	D U D	N2212 TA124EK N2112 TC144EK N2213	DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E 1 E 1
92 92 93 94 94		2SC2412K 2SD601A 2SA1037K DTC124EK UN2212	TRANSISTOR TRANSISTOR TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR		Q51 Q52 Q52 ,53 Q60 Q60	2: 2: D	SA1037K SK536 SK536 TC124EK N2212	TRANSISTOR FET FET DIGITAL TRANSISTOR DIGITAL TRANSISTOR	E1 K1M2 E1
95 96 96 97		2SB1184 DTC114YK UN2214 2SB1443 2SD2396F40	TRANSISTOR DIGITAL TRANSISTOR DIGITAL TRANSISTOR TRANSISTOR TRANSISTOR		Q61 Q61 Q62 Q62 Q64 -67	2:	SC2412K SD601A SC2412K SD601A SD2114K	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	K1M2 K1M2 E1 E1

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without **Parts No.** are not supplied. Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

ELECTRIC UNIT (X25-781X-XX) K1:0-11 M2:0-22 E1:2-71 CD PLAYER UNIT (X32-4290-00)

Ref No.	Parts No.		Description/Destination			Ref No.	N e v	Parts No.	Description/Destination			
Q70 ,71 Q70 ,71 Q72 Q72 Q74		DTC124EK UN2212 2SC2412K 2SD601A DTA124EK	DIGITAL TRAN DIGITAL TRAN TRANSISTOR TRANSISTOR DIGITAL TRAN	SIST 0 R	E1	C31 C41 C42 C43 C44		CK73EB1C105K C92-1335-05 CK73EB1H104K CK73FB1H123K CK73FB1C104K	CHIP C ELECTRO CHIP C CHIP C CHIP C	1.0UF 4.7UF 0.10UF 0.012UF 0.10UF	K 16WV K K K	
974 975 975 976 976		UN2112 2SC2412K 2SD601A DTC124EK UN2212	DIGITAL TRAN TRANSISTOR TRANSISTOR DIGITAL TRAN DIGITAL TRAN	SISTOR	E1 E1 E1	C45 C51 C52 C61 C63		CK73FB1H223KTA C92-0005-05 CK73FB1H103K CK73EB1C105K C92-0509-05	CHIP C CHIP-TAN CHIP C CHIP C CHIP-TAN	0.022UF 2.2UF 0.010UF 1.0UF	K 6.3WV K K 6.3WV	
Q77 Q78 Q78 Q79 Q80		2SB1277(Q,R) DTC114TK UN2215 2SB1277(Q,R) DTB123YK	TRANSISTOR DIGITAL TRAN DIGITAL TRAN TRANSISTOR DIGITAL TRAN	SISTOR	E1 E1 K1	C65 ,66 C67 ,68 C71 ,72 C73 ,74 C75 -78		CK73FB1C104K C92-0004-05 CC73FCH1H101J CC73FCH1H121J CC73FCH1H270J	CHIP C CHIP-TAN CHIP C CHIP C CHIP C	0.10UF 1.0UF 100PF 120PF 27PF	K 16WV J J J	
Q82 Q82 Q82 ,83		2SC2412K 2SD601A 2SC2412K	TRANSISTOR TRANSISTOR TRANSISTOR		K1M2 K1M2 E1	C79 ,80		CK73FB1H222K E40-9536-05	CHIP C FLAT CABLE C	2200PF	K	
Q82 ,83 Q84		2SD601A DTC114TK	TRANSISTOR DIGITAL TRAN	SIST O R	Ē1	CN2		E40-9339-05 L40-1001-31	FLAT CABLE C	ONNECTOR	101111	
Q84 Q85 Q85 Q86		UN2215 DTA144EK UN2113 2SC2412K	DIGITAL TRAN DIGITAL TRAN DIGITAL TRAN TRANSISTOR	SISTOR	E1	L2 X1 X2		L79-0914-05 L78-0620-05 L78-0528-05	SMALL FIXED LC FILTER RESONATOR RESONATOR	INDUCTOR	100#)	
Q86 TH1		2SD601A NT732ATD33KJ	TRANSISTOR THERMISTOR		E1	R1 R2 R3		RK73FB2A243J RK73FB2A183J RK73FB2A154J	CHIP R CHIP R CHIP R	24K J 18K J 150K J	1/10W 1/10W 1/10W	
A 1		W02-1523-05	FM/AM FRONT-		E1	R4 R5		RK73FB2A155J RK73FB2A910J	CHIP R CHIP R	1.5M J 91 J	1/10W 1/10W	
A1		CD PLAYER U	FM/AM FRONT- NIT (X32-42 9		K1M2	R6 R7		RK73FB2A154J RK73FB2A155J	CHIP R CHIP R	150K J 1.5 M J	1/10W 1/10W	
C1 ,2 C3 ,4 C5 C6		CK73EB1C105K C92-0509-05 CC73FCH1H220J CC73FCH1H020C	CHIP C CHIP-TAN CHIP C CHIP C	1.0UF 10UF 22PF 2.0PF	K 6.3WV J C	R8 R9 R10 ,11		RK73EB2B4R7J RK73EB2B100J RK73FB2A912J	CHIP R CHIP R CHIP R	4.7 J 10 J 9.1K J	1/8W 1/8W 1/10W	
C7 C8 C9 C10		CK73FB1C104K CK73EB1C105K CC73FCH1H101J CK73FB1H682K	CHIP C CHIP C CHIP C CHIP C	0.10UF 1.0UF 100PF 6800PF	K K J K	R12 R13 R14 ,15 R16 R17		RK73FB2A562J RK73FB2A683J RK73FB2A824J RK73FB2A223J RK73FB2A393J	CHIP R CHIP R CHIP R CHIP R CHIP R	5.6K J 68K J 820K J 22K J 39K J	1/10W 1/10W 1/10W 1/10W 1/10W	
C11 ,12 C13		CK73FB1H222K CK73FB1E273KTA	CHIP C	2200PF 0.027UF	K K	R18 R19		RK73FB2A392J RK73FB2A333J	CHIP R CHIP R	3.9K J 33K J	1/10W 1/10W	
C14 C15 C16 C17		CK73FB1H472K CK73FB1E473KTA CC73FCH1H101J CK73FB1H222K	CHIP C CHIP C CHIP C CHIP C	4700PF 0.047UF 100PF 2200PF	K K J K	R20 R21 R31		RK73FB2A104J RK73FB2A224J RK73FB2A102J	CHIP R CHIP R CHIP R	100K J 220K J 1.0K J	1/10W 1/10W 1/10W	
C18 C19 ,20		CC73FCH1H391J CK73FB1C104K	CHIP C	390PF 0.10UF	J K	R32 R33 R34		RK73FB2A104J RK73FB2A155J RK73FB2A333J	CHIP R CHIP R CHIP R	100K J 1.5M J 33K J	1/10W	
C21 C22 C23		C92-0509-05 CK73FB1C104K CK73FB1H102K	CHIP-TAN CHIP C CHIP C	10UF 0.10UF 1000PF	6.3 W V K K	R35 R36		RK73FB2A104J RK73FB2A111J	CHIP R CHIP R	100K J 110 J	1/10W 1/10W 1/10W	
C24 C25 C26 C27		CK73FB1H223KTA CK73FB1H123K CK73FB1C104K CC73FCH1H101J	CHIP C CHIP C CHIP C	0.022UF 0.012UF 0.10UF 100PF	K K J	R37 R38 R41 R42 R43		RK73FB2A471J RK73FB2A224J RK73FB2A101J RK73FB2A104J RK73FB2A101J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K J	1/10W 1/10W 1/10W 1/10W 1/10W	
C28 C29		CK73EB1C105K CK73FB1H102K	CHIP C	1.0UF 1000PF	K K	R44		RK73FB2A102J	CHIP R	1.0K J	1/10W	

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

CD PLAYER UNIT (X32-4290-00) MECHANISM ASSY (X92-3190-00)

Ref No.	N e w	Parts No.	Descript	ion/Destina	ition	Ref N	lo.	N e w	Parts No.	CHANISM ASSY (X92-3190-00 Description/Destination
R45		RK73FB2A103J	CHIP R	10K J	1/10W	Q6		VV	2SA1037K	TRANSISTOR
R46		RK73FB2A102J	CHIP R	1.0K J	1/10W	-		ш		ASSY (X92-3190-00)
R47 R48 -50 R51		RK73FB2A103J RK73FB2A472J RK73FB2A101J	CHIP R CHIP R CHIP R	10K J 4.7K J 100 J	1/10W 1/10W 1/10W	1 2 3	2A 1B 2B		A10-4224-31 A10-4225-13 A11-0915-23	CHASSIS CHASSIS CALKING ASSY SUB CHASSIS CALKING ASSY
R52 R53 R54 R55 R56		RK73FB2A104J RK73FB2A101J RK73FB2A104J RK73FB2A101J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	100K J 100 J 100K J 100 J 100K J	1/10W 1/10W 1/10W 1/10W 1/10W	4 5 5A 6 7	3B 2A 2A 2A 2A	*	D02-0209-03 D10-3082-13 D10-4038-13 D10-3083-34 D10-3084-34	TURNTABLE PLATTER ARM ARM ASSY ARM ASSY ARM ASSY
R57 R58 -64 R65 ,66 R67 R68		RK73FB2A472J RK73FB2A101J RK73FB2A472J RK73FB2A101J RK73FB2A104J	CHIP R CHIP R CHIP R CHIP R CHIP R	4.7K J 100 J 4.7K J 100 J 100K J	1/10W 1/10W 1/10W 1/10W 1/10W	8 9 10 11 12	3A 3B 3B 2B 2B		D10-3087-24 D10-3092-03 D10-3093-04 D10-3095-04 D10-3096-04	ARM ASSY SLIDER SLIDER ASSY SLIDER ASSY SLIDER ASSY SLIDER ASSY
R69 R71 R72 R73 R74		RK73FB2A101J RK73FB2A752J RK73FB2A102J RK73FB2A333J RK73FB2A123J	CHIP R CHIP R CHIP R CHIP R	100 J 7.5K J 1.0K J 33K J 12K J	1/10W 1/10W 1/10W 1/10W 1/10W	15 16	2A	* *	D10-3099-04 D10-3100-04 D10-4123-04 D10-4004-04 D10-4006-04	SLIDER ASSY SLIDER ASSY LEVER ASSY LEVER ASSY LEVER ASSY
R75 R76 R77 R78 R79		RK73FB2A273J RK73FB2A512J RK73FB2A393J RK73FB2A153J RK73FB2A202J	CHIP R CHIP R CHIP R CHIP R CHIP R	27K J 5.1K J 39K J 15K J 2.0K J	1/10W 1/10W 1/10W 1/10W 1/10W	18 19	1 A 2 B 2 A	*	D10-4007-04 D10-4008-04 D10-4009-03 D10-4010-04 D10-4011-24	LEVER LEVER LEVER LEVER
R80 R81 R82 R83 R91		RK73FB2A162J RK73FB2A273J RK73FB2A562J RK73FB2A561J RK73FB2A753J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.6K J 27K J 5.6K J 560 J 75K J	1/10W 1/10W 1/10W 1/10W 1/10W	23 24 27	3A 3B 3B 3B	* * *	D10-4013-04 D10-4050-04 D13-1229-13 D13-1230-14 D13-1231-04	LEVER ASSY ARM ASSY ARM RACK (GEAR) WORM
R92 R101,102 R103,104 R111-114 R115-118		RK73FB2A102J RK73FB2A241J RK73FB2A122J RK73FB2A513J RK73FB2A473J	CHIP R CHIP R CHIP R CHIP R CHIP R	1.0K J 240 J 1.2K J 51K J 47K J	1/10W 1/10W 1/10W 1/10W 1/10W	30 31 32 33	3B 3B 3B	* * * *	D13-1232-04 D13-1233-04 D13-1234-14 D13-1238-03	GEAR GEAR GEAR ASSY GEAR
R119-122 R123-126 R127,128 V1		RK73FB2A393J RK73FB2A683J RK73FB2A681J R92-2052-05 R92-2053-05	CHIP R CHIP R CHIP R CHIP R CHIP R	39K J 68K J 680 J 0 J	1/10W 1/10W 1/10W 1/10W 1/10W	35 36 37 38	3B 3B 1B 1B	* * *	D13-1241-04 D13-1241-04 D13-1242-04 D13-1243-04 D13-1244-04	GEAR GEAR GEAR GEAR GEAR
51 ,2 53	*	S68-0822-05 S68-0823-05	PUSH SWITCH PUSH SWITCH						D13-1245-14 D13-1246-04	GEAR GEAR
01 ,2 [C1 [C2 [C3		DAN202K AN8806SB MN662724RPE M37471M8-368FP	DIODE ANALOGUE IC MOS-IC MI-COM IC			41 42 43	2B 2B 2B	* *	D13-1247-04 D13-1248-04 D13-1249-04 D14-0668-04	GEAR GEAR GEAR GEAR ASSY ROLLER
IC4 IC5 IC6 IC7		BA6790FP KKZO5F TA78L05F NJM5532MD 2SA1362(Y)	ANALOGUE IC CUSTOM IC IC(VOLTAGE RI IC(OP AMP) TRANSISTOR	EGUL ATO R/	+5V)	47 48 49	2B 3B	*	D14-0670-04 D14-0674-04 D19-0613-14 D21-2228-04 D21-2229-04	ROLLER ROLLER LEAD SCREW SHAFT SHAFT
92 93 ,4 95		DTC124EK 2SA1362(Y) DTC124EK	DIGITAL TRANS TRANSISTOR DIGITAL TRANS			52 53	1 A 2 A 1 B 2 B	*	D23-0925-04 D32-0614-04 D39-0223-05 D39-0224-05	RETAINER STOPPER DAMPER DAMPER

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

PARTS LIST

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

MECHANISM ASSY (X92-3190-00)

Ref I	No.	N e w	Parts No.	Description/Destination
-			F09-1246-04	SHEET(M1)
60 61 62 63 64	2B 3A 3A 3A 3A	* * *	C01-2770-04 G01-2771-04 G01-2772-14 G01-2773-14 G01-2774-34	EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING EXTENSION SPRING
65 66 67 68 69	1B 1B 3B 3A 2A	* * *	G01-2775-04 G01-2776-14 G01-2777-14 G01-2824-14 G01-2844-04	TORSION COIL SPRING TORSION COIL SPRING TORSION COIL SPRING COMPRESSION SPRING EXTENSION SPRING
70 71 72 73	2A 2B 2A 2A	* *	G02-1231-04 G02-1232-04 G02-1241-24 G02-1248-14	FLAT SPRING FLAT SPRING FLAT SPRING FLAT SPRING
75 76 77 78 79	2A 3A 2B 3B 2B	* *	J11-0613-03 J19-4678-13 J19-4679-14 J21-7684-03 J21-7686-03	CLAMPER HOLDER HOLDER MOUNTING HARDWARE MOUNTING HARDWARE
80 81 82 83	ЗА	* * *	J21-7690-03 J31-1032-04 J84-0060-05 J90-0757-12	MOUNTING HARDWARE COLLAR FLEXIBLE PRINTED WIRING BOARD GUIDE
A B C D E	2A 1B 2B 2A 3A	* *	N09-4158-05 N09-4172-05 N09-4187-05 N38-2020-46 N82-2006-46	MACHINE SCREW (M1.7X2.5ヒラ,カフ) TAPPING SCREW (2X3.5,Cタイト) MACHINE SCREW (M1.7X4,ヒラ,カフ°) PAN HEAD MACHIN SCREW BINDING HEAD TAPTITE SCREW
F G	1B 2B		N19-2023-04 N19-2058-04	FLAT WASHER FLAT WASHER
M1 M2 PU1	3B 3B 2B		T42-0764-04 T42-0763-04 T25-0209-05	DC MOTOR DC MOTOR OPTICAL PICKUP HEAD

K1: KDC-8007

M2: KDC-8008

E1: KDC-9050R

SPECIFICATIONS

FM tuner section (KDC-8007/8008 only)	LW tuner section (KDC-9050R only)
Frequency range (Frequency step)	Frequency range (Frequency step) 153kHz~281kHz
8007 87.9MHz~107.9MHz (200kHz)	Usable sensitivity (S/N=20dB)45μV
8008 87.5MHz~108.0MHz (50kHz)	
Channel space selection	CD section
8007 200kHz Fix	Laser diodeGaAlAs (λ=780nm)
8008 50kHz/200kHz Switchable	Digital filter (D/A)
Usable sensitivity (S/N=30dB) 9.3dBf (0.8μV/75Ω)	D/A converter 1 Bit
Quieting sensitivity (S/N=50dB) 15.2dBf (1.6μV/75Ω)	Spindle speed 500~200 (CLV)
Frequency response (±3.0dB) 30Hz~15kHz	Wow & Flutter Below measurable limit
Signal to Noise ratio (MONO)	Frequency response (±1dB) 10~20kHz
Selectivity (dB) ≥ 80dB (±400kHz)	Total harmonic distortion 0.01% (1kHz)
Stereo separation (1kHz)	Signal to Noise ratio (1kHz) 105dB
	Dynamic range 100dB
FM tuner section (KDC-9050R only)	Chanel separation85dB
Frequency range (Frequency step)	
87.5MHz~108.0MHz (50kHz)	Audio section
Usable sensitivity (S/N=26dB)	Preout level (mV)/Load400mV/10k Ω
Quieting sensitivity (S/N=46dB)	Preout impedance 80Ω
Frequency response (±3.0dB)	Amp power
Signal to Noise ratio (MONO)	Max 35W x 4
Selectivity (dB) ≥ 80dB (±400kHz)	Fullbandwidth, less than 1% THD 20W $ imes$ 4
Stereo separation (1kHz)	(8007/8008 only)
	DIN45324, +B=14.4V 25W x 4 (9050R only)
AM tuner section (KDC-8007/8008 only)	Tone action
Frequency range (Frequency step)	Bass100Hz±10dB
8007 530kHz~1700kHz (10kHz)	Treble10kHz±10dB
8008 531kHz~1611kHz (9kHz)	
Channel space selection	General
8007 10kHz fix	Operating voltage 14.4V (11~16V allowable)
80089k/10kHz switchable	Current consumption 10A at rated power
Usable sensitivity (S/N=20dB)	Installation size (W x H x D) 182 x 53 x 165 (mm)
	$7-3/16 \times 2-1/16 \times 6-1/2$ (inch)
MW tuner section (KDC-9050R only)	Weight (net) 1.8kg (4.0Lbs)
Frequency range (Frequency step)	
531kHz~1611kHz (9kHz)	KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.
Usable sensitivity (S/N=20dB)30μV	1 1

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo, 150 Japan

KENWOOD SERVICE CORPORATION

P.O. Box 22745, 2201 East Dominguez Street, Long Beach, CA90801-5745, U.S.A.

KENWOOD ELECTRONICS CANADA INC. 6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS LATIN AMERICA S.A.
P.O. Box 55-2791, Piso 6, Plaza Chase, Cl. 47 y, Aquilino de la Guardia, Panama, Republic of Panama

KENWOOD ELECTRONICS BRASIL LTDA. Avenida Indianópolis, 628, 04062-001 Planalto Paulista, São Paulo-SP-Brasil

KENWOOD ELECTRONICS UK LIMITED

Kenwood House, Dwight Road, Watford, Herts, WD1 8EB, United Kingdom

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

KENWOOD ELECTRONICS FRANCE S.A.

KENWOOD ELECTRONICS BELGIUM N.V. Mechelsesteenweg 418, B-1930 Zaventem, Belgiun

KENWOOD ELECTRONICS ITALIA S.p.A.

KENWOOD IBÉRICA S.A.

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD. (A.C.N. 001 499 074)

8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS LTD.
Unit 3712-3724, Level 37. Tower 1, Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T., Hong Kong

KENWOOD ELECTRONICS GULF FZE P.O. Box 61318, Jebel Ali, Dubai, U.A.E.

KENWOOD ELECTRONICS (THAILAND) CO., LTD.

573/111 Soi Ramkhamhaeng 39, Ramkhamhaeng Road, Wangthonglang, Bangkapi, Bangkok, 10310 Thailand

KENWOOD ELECTRONICS SINGAPORE PTE. LTD.

KENWOOD ELECTRONICS (MALAYSIA) SDN BHD #4.01 Level 4, Wisma Academy, Lot 4A, Jalan 19/1, 46300 Petaling Jaya, Selangor Malaysia